


doorclosingmeter.com
glasmacher electronic GmbH

Bluetooth Adapter




Plug-in Bluetooth Adapter can be removed by lifting it off the main PCB





Use the free Android App „TGMscan“ to get the TGM results to a smartphone, assign the result to a door and a car and share the results

<https://glasmacher-electronic.com/TGMbluetooth.mp4>

We offer a special Bluetooth USB Receiver and a Windows Software to receive the TGM Result on a Windows PC Com Port as ASCII String or Keystroke into for example EXCEL



Jumper open – Bluetooth Adapter Power OFF



Jumper closed – Bluetooth Adapter Power ON while TGM turned ON
Needs around 8mA – so Power Consumption of TGM with Bluetooth Adapter double to TGM without



Short Video of the TGMscan App

email@glasmacher-electronic.de



doorclosingmeter.com

glasmacher electronic GmbH


1. Open the battery compartment



2. Disconnect the battery




3. Unscrew two screws to open the upper casing




4. Bend the casing a bit top open it



5. Disconnect the brown plug

 Unplug the Battery!!

1. Pull plug and unscrew jack plug from outer case



email@glasmacher-electronic.de

Replacing the TGM USB connection with the TGM Bluetooth Adapter

3. The Bluetooth adapter is ON when the bridge on the upper side is set – the power consumption is around 8mA

2. Plug Bluetooth adapter on the 3 pinheaders

